



To set up the Cubelite system for the first time the procedure is as follows:

1. Lay each item on the floor. You should have:
 1. 1 x Cubelite
 2. 1 x Tungsten Light
 3. 1 x 500w bulb
 4. 1 x Light stand
 5. 1 x Silver/white reflector
 6. 1 x White background
 7. 2 x Metal clips
 8. 1 x Carry case
2. Remove the Cubelite from it's blue circular carry case.
3. Let it spring open to form a rounded square shape.
4. Open it out to form a right angle shape.
5. Pull the middle section out diagonally and manouver the steel to form the cube shape. It should spring into shape.
6. Give the whole cube a shake if it doesn't spring into shape.
7. Place the Cubelite onto your table or chosen work surface.
8. Remove the front panel and store if not required.
9. Remove the background from the tube.
10. Attach inside the Cubelite using the sewn in elastic loops and the 2 x clips provided.
11. Remove the stand from box.
12. Pull out the three legs to form a tripod structure, lock them in place and stand it up
13. Remove the protective plastic moulding from the top.
14. Remove light unit from box.
15. Attach light to the top of the stand and tighten the knob to secure. **DO NOT** plug the light in yet.
16. Remove bulb from box.
17. Screw into the light unit. **DO NOT** plug the light in yet.
18. Position the lamp approx' 18 inches from the Cubelite.
19. Remove the reflector from it's packaging.
20. Allow to spring open forming a rounded square shape.
21. Position the reflector inside the Cubelite on the opposite side to the light.
22. The Cubelite is now ready to take your first image.
23. Position the products to be photographed inside the Cubelite to your liking.
24. Position your camera and tripod and frame the shot in your viewfinder or LCD monitor.
25. Position the light to your liking, plug it into the wall socket and switch it on.
26. Manouver the reflector until you are happy with the lighting and shadows and then take the shot.